

# **Bottle Vac Sampling:**

- Remove bottle vac from box and fill out the Technology Laboratory, Inc. (TLI) sample label with all requested information.
- Purge all flexible tubing with the sample being obtained to remove dead air **before attaching to the Swagelok valve.**
- Make sure Swagelok valve is turned to the closed position (perpendicular to the sample tubing).
- Attach the flexible tubing to the Swagelok valve apparatus.
- Connect the spring-loaded quick-connect to the top of the bottle vac.
- Turn the Swagelok valve parallel to the sample tubing to open the entire apparatus to the evacuated bottle vac.
- Wait a few minutes for the bottle vac to completely fill with sample.
- Close Swagelok valve perpendicular to sample tubing, remove Swagelok apparatus from the bottle vac by releasing the spring-loaded quick-connect.
- Remove flexible tubing from the Swagelok apparatus.
- Place bottle vac back in the box.
- Make sure to purge flexible sample tubing with the next sample before re-connecting.

Please contact us if you have any questions:

**Technology Laboratory, Inc.**  
**1012 Centre Avenue**  
**Fort Collins, CO 80526**  
**Phone: 970-490-1414**  
**Fax: 970-472-5488**  
**[www.techlabusa.com](http://www.techlabusa.com)**